

### INSTALLATION INSTRUCTIONS

#### PART #4056 I Sumatra™ 4000 SERIES SideSteps™

#### 1995-01 BLAZER S-10 / JIMMY 4DR BRAVADO



**Do not attempt to install this product on any vehicle other than the one it is designed for and listed above!**

#### Packing List

Quantity	Description	Quantity	Description
4	1/2" X 2' HEX BOLTS	1	4056P SIDE STEP PASSENGER SIDE
4	12MM X 120MM HEX BOLTS	1	4056D SIDE STEP DRIVER SIDE
8	1/2" LOCK WASHERS	2	4056F FRONT MOUNTING BRACKETS
8	1/2" FLAT WASHERS	2	4028F REAR MOUNTING BRACKETS
2	4056SP SPACER PLATES		

**WARNING** Carefully read all the instructions prior to attempting to install this product. If you are not familiar with using workshop tools or with workshop safety practices, take the product and vehicle to a skilled installer. Go Rhino! Products accept no responsibility for any damage or injuries that may result from the product(s) being incorrectly installed. Before attempting to install accessories, park the vehicle on flat level ground, apply the emergency brake and disconnect the battery. If installation requires the use of a jack or lift, use only one with the correct load rating for the vehicle, follow the manufacturer's instructions and use wheel chocks. After installation, check the operation of all lights and turn signals; periodically check all fasteners for tightness. Retighten only loose fasteners as over-tightening snug fasteners can result in breaking or stripping them. Failure to maintain tightness of fasteners could result in the product detaching itself from the vehicle and possibly jamming wheels etc. This condition could cause serious personal bodily injury.

**STEP 1.** REMOVE CONTENTS FROM SHIPPING CARTON AND CHECK PARTS WITH PARTS LISTED ABOVE.

**STEP 2.** READ INSTRUCTIONS COMPLETELY BEFORE BEGINNING INSTALLATIONS.

**STEP 3.** ATTACH BOTH FRONT AND REAR MOUNTING BRACKETS TO SIDE STEPS USING 1/2" X 2" HEX BOLTS, LOCK WASHERS AND FLAT WASHERS (AS SHOWN IN DIAGRAM). DO NOT TIGHTEN!

**STEP 4.** REMOVE THE STOCK (OE) BODY MOUNTING BOLTS FROM BODY MOUNTS LOCATED UNDER THE CAB OF THE TRUCK.

**STEP 5.** POSITION THE SIDE STEP ASSEMBLY UP TO THE FRONT BODY MOUNT AND ATTACH USING 12MM X 120MM HEX BOLTS, LOCK WASHERS AND FLAT WASHERS (AS SHOWN IN DIAGRAM).

**STEP 6.** ALIGN SIDE STEPS WITH BODY; THEN TIGHTEN AND TORQUE MOUNTING BRACKET AND SIDE STEP BOLTS (1/2" = 65 FT. LBS.) (12MM = 55 FT. LBS.)

**FOR TECHNICAL OR WARRANTY INFORMATION CALL:**  
**GO RHINO! Products® • XtremeRack™ • QuickRack®**  
 591 W. Apollo St. Brea, CA 92821  
 (714)257-7389 (888)427-4466 FAX(714)672-0278

[www.gorhino.com](http://www.gorhino.com) • [www.xtremetracks.com](http://www.xtremetracks.com) • [www.quickrack.com](http://www.quickrack.com)